

## Johannus MIDI Sequencer + LDS Hymn Player Setup and Use

### Connecting the Hymn Player to the organ:

1. Connect the MIDI cable to the MIDI IN port on the organ and the MIDI OUT port on the hymn player.

### Entering Hymn Mode (only needs to be done upon first use):

1. Insert SD Card.
2. Press < and ■ to enter the menu.
3. Using the data wheel, scroll to Options. Press the data wheel to view options.
4. Scroll to Hymn Mode.
5. Press < or > to select ON for Hymn Mode.
6. Scroll to Back and press the data wheel.
7. Scroll to Play/Browse and press the data wheel.
8. The MIDI Sequencer + is now in Hymn Mode. It will stay in Hymn Mode until manually disabled.

### Play a hymn:

1. Turn power on.
2. Make sure SD card is inserted.
3. Make sure the player is in Hymn Mode. This is shown by the letters "HM" in the top right corner of the display.
4. Select stops on the organ.
5. Using the data wheel, select the hymn you wish to play. If you select a hymn number with "I" at the beginning, an introduction will be played first.
6. Press ► to begin introction.
7. Press > to add a verse (shown on third line of display). (< removes a verse)
8. The data wheel controls volume.